

# Solid State Physics


# Structure of Matter

- Macroscopic Matter
- Molecules ( $\sim 10^{23} \text{ cm}^{-3}$ )
- Atoms
- Electrons, protons, neutrons
- Quarks

# States of Matter




- Solid
  - Have definite shape, volume, strong interaction
- Liquid
  - Shapeless, intermediate interaction
- Gas
  - Free atoms or molecules, weak interaction
- Plasma
  - A collection of free, charged particles

# Condensed Matter Systems



# Arrangement of Atoms in Solids

- Crystalline
  - A regular arrangement of atoms with long-range order
- Polycrystalline
  - Short range order but no long range order
- Amorphous
  - Random arrangement of atoms






# Crystalline Solids by Bond Types

- Atomic crystals
  - Noble gases (He, Ne, Ar)
  - Chemically inert, soft, low melting point, poor thermal and electrical conduction
- Molecular crystals
  - Many polymers, molecular gases
  - Somewhat soft, moderate melting point, poor thermal and electrical conduction
- Ionic crystals
  - Crystal sites are occupied by positive and negative charged ions
  - Coulombic interactions dominate
  - Hard, high melting temperatures, poor thermal and electrical conduction
- Metallic crystals
  - Soft to hard, high melting temperatures, excellent thermal and electrical conductors
- Covalent crystals
  - Strong bonding
  - Hard, high melting temperatures, poor thermal and electrical conductors


# Crystal Lattices

- A unit cell is the smallest arrangement of atoms that has all the information necessary to build the lattice.
- Simple, body centered, face centered cubic lattices.





# Band Structure

- Single molecules (or atoms) have their electrons in discrete energy levels.
- As molecules get closer, the energy levels will split into multiple levels.
- When many molecules come together to form a crystal, the multiple levels merge into continuous energy bands separated by forbidden zones (band gaps).



# Band Filling

- In the ground state, electrons fill the available energy levels from the bottom.
- If highest occupied band is only partially filled, the electrons are energetically allowed to move about the crystal and the material is a conductor.
- If the highest band is fully occupied, then the electrons are energetically bound and the material is an insulator.




# Electrons and Holes

- If an electron somehow gets excited to a higher energy level and moves away from its parent atom, it leaves behind an empty orbital which acts as a positively charged particle – a hole.
- Together, free electrons and holes are called carriers.
- The density of free electrons is called  $n$ , and holes,  $p$ .
- Electrons and holes can get attracted to each other and form a neutral particle called an exciton.
- The electron can return to its ground state, ie. recombine with a hole and release its extra energy, either as light (photon), a lattice vibration (phonon) or transfer it to another electron.


# Fermi Level

- The Fermi level is the energy of the highest occupied level at 0 K.
- As the temperature is increased, there is a finite possibility of higher levels being occupied.



# Density of States

- It is an integrated measure of the available energy levels and the possible number of electrons in them.




# Semiconductors

- A semiconductor is really an insulator with a smaller band gap.
- A perfect semiconductor has no free electrons, the valence band is completely filled and the conduction band is completely empty.
- At finite temperatures, some electrons are thermally excited and break their bonds to become free leaving behind holes.
- In thermal equilibrium,  $np = \text{constant}$
- For a pure (intrinsic) semiconductor,  $n=p=n_i$ 
  - for Si,  $n = p \sim 10^{10} \text{ cm}^{-3}$


# Doping

- Doping is the controlled addition of impurity atoms to a host material.
- If the impurity has an extra electron to supply to the host, it is called a donor.
- If the impurity receives an electron from the host, it is an acceptor.
- Donors create extra energy levels near the conduction band.
- Acceptors create extra energy levels near the valence band.
- Once the doping level exceeds the intrinsic carrier concentration, the semiconductor is said to be doped.



# X-Ray Diffraction

- Send x-rays to the crystal.
- The rays scatter off of atomic layers and interfere with each other.
- Record the pattern as a function of angle of incidence.



$$\lambda = 2d_{hkl} \sin \theta$$

